

2014-2019 Conform Chrome Air Dam Insert

1. Clean surface with 70% rubbing alcohol & paper towel.
 2. With backing paper on, set one side of the part in the center of the air dam. Be sure to account for the opposite side fitment so both sides fit evenly within the surface.
 3. Mark surface with grease pencil for alignment. (see below)
 4. Peel back 1/2 of the backing paper exposing the adhesive. Leave a tab at the bottom or top that you can use to pull the remaining paper off the back while pressing into place.
 5. Place inner leading edge at your center marks. Slowly press down into place from the inside center working your way to outside using overlapping strokes. (A micro fiber cloth works well to allow for slide.) Repeat on opposite side.
- *When pressing into place be sure to hold the part just above the surface not allowing the adhesive to touch until you press it into place. Sticking in advance of pushing it down can cause air bubbles below surface.

