

# *Bellerdine Web, Fitment Schematic RT Spyder*

## Elements:

4 piece Vinyl cut- Web

1 Bellerdine Isolated Spider



**NOTE:** The final placement of the spider element will be up to you. The web will be applied first then you will put the spider on top as desired. To simplify application, The 4 piece web was created not to connect on the frunk. A 1/4' or less gap is normal.

