

F3 Boomerang Application Tips

Your boomerang kit has a top protective transfer tape on it. This is to help keep the product more rigid during application & prevent overstretch. The transfer tape can be removed at any time if you feel it is limiting your ability to apply it. (if removed use caution not to over stretch) Alignment may take several attempts before you get the proper angle & center. Once in position, lightly press into place using your thumb. Make several passes over the top to make sure the product is secure. Peel transfer tape. Use light heat to warm the surface after application. Softly press down on the film with a microfiber towel.

- ** See the Arrow label on the product for start point. Make sure the legs fall into place in the center of the panel or your alignment will be off.
- * This is a dry installation **Do Not Apply Wet.**
- * Install in 65 degrees F. or warmer
- * Do not apply in direct sunlight or outdoors if windy.



Call or text questions: 814-450-1923

F3 Side Panel Can-am
Text Overlay sold separately