

F3 Touring / Limited Faring Accent Kit

**** Please read before applying**

Apply your pieces in the order shown below 1-12. Use the photo and suggested gaps as a guide for panel spacing. Let the pieces fall into place naturally.

It may take several attempts to get the piece to fall into place as desired. Each piece was created to fit within the body lines of the panel.

A slight gap between each piece is normal (see photo below). For best results, apply your kit in a garage out of the wind & dust.

Use extreme caution to not to overstretch the wrap when applying or when transferring off the paper to the bike..

Do not apply in high humidity and temps above 80 degrees F. Do not apply in direct sunlight or in open air. ****Do not apply wet. ** Post heat once applied**

**** Call or text with questions 814-450-1923**

