

F3 Boomerang PVC Chrome Application Tips

** Your boomerang kit has a clear top protective Mylar on it. This is to help prevent scratches during application and is to be removed once applied. It is not uncommon to have what appears to be jagged black edges with the Mylar still on the part. This appearance is only in the Mylar and once it is removed will disappear.

When applying, we recommend you dry set the part to get a feel for fitment and alignment before you start. Use 70% Alcohol and paper towel to clean. All wax and silicone base products must be removed. If your bike was professionally ceramic coated do not apply this kit.

To start, peel back and expose the adhesive from the point back to where the 2 legs begin. Do not touch adhesive. Cut paper off so you now have 2 sides, top and bottom. Carefully align the point so it falls in the center of panel and the legs fall evenly in their designated location. Tack the center firmly by pressing it down into place. **DO NOT lift it off the surface once tacked into place.** Once tacked at the point, you now have a top and bottom with the paper backing still attached. Choose a leg and peel back 4" or so of the paper exposing the adhesive on the leg. Hover the leg evenly over the surface but **DO NOT set it down until centered.** You can use your fingers on the top and bottom edge of the part as a guide to find center before setting it down. Once in the center, press into place. **DO NOT lift off surface once applied.** Using the same technique work your way back to the end of the leg. Repeat process for the opposite leg.

Once applied, Softly press down on the part with a micro fiber towel, use light heat (hair dryer) to warm the surface to help ensure good adhesion. Lastly, Peel the Mylar off the top to expose your beautiful chrome finish. Clean with warm soapy water, do not use harsh or abrasive products on the chrome.

** See the Arrow label on the product for start point. Make sure the legs fall into place in the center of the panel or your alignment will be off.
** **Do not set the panel down on the surface and then try to pick it back up. If you do you will ruin the adhesive on the part.**

* This is a dry installation **Do Not Apply Wet.**

* Install in 65 degrees F. or warmer

* Do not apply in direct sunlight or outdoors if windy.



Work from the point to the end of each tail. Make sure you align in the center of the panel as you work back.

***DO NOT set on surface and try to pull back up.**

Start Installation Here at the Point